

# 350Z-RKBK

1. PRESS OUT ALL OEM SUSPENSION BUSHINGS

36 mm DIAMETER  
50 mm SPACING

2. APPLY LOCTITE BEARING ADHESIVE (MEDIUM STRENGTH IS SUFFICIENT) \*RECOMMENDED

36 mm DIAMETER  
40 mm SPACING

31 mm DIAMETER  
40 mm SPACING

3. PRESS IN NEW SPHERICAL BEARING HOUSINGS WITH BEARING AND CIRCLIP INSTALLED FROM CIRCLIP SIDE. PRESS DRIFT TO SEAT ON EDGE SHOWN. DO NOT PRESS ON BEARING INNER BALL

36 mm DIAMETER  
50 mm SPACING

