

SR20-SWRL

1. **Install bleed screw adapter into water neck (6-8Nm)**
2. **Install 34mm sensor adapter with barb into lower radiator hose**
3. **OEM radiator cap to be installed onto swirl pot**
4. **Blank radiator cap to be installed on radiator**
5. **Mount bracket to chassis using top bolt and use as a guide to drill bottom bolt hole.**
6. **Mount swirl pot to bracket**
7. **Install all hoses prior to mounting to chassis for ease of access**
8. **Mount bracket to chassis using supplied hardware**

