


CRITICAL!

SPACERS ARE TO BE STACKED CONCENTRIC TO ONE ANOTHER. THEY ARE DESIGNED TO ADJUST CASTER SETTINGS AND COMPENSATE FOR EXTENDING THE REAR ROD END FOR ADJUSTING TRACK WIDTH AND CHASSIS CLEARANCE.


MINIMUM SPACER PER SIDE IS ONE. ROD END NEEDS TO BE ADJUSTED TO SUIT

NB! ENSURE THERE IS NO BINDING OF THE ROD END BEARINGS AFTER ADJUSTING THE ARM LENGTH


CHECK BY PUSHING THE ARM UP AND DOWN WITH IT DISCONNECTED FROM THE STEERING KNUCKLE




FRONT ROD END (TENSION) - OEM SPEC







REAR ROD END (LCA) - OEM SPEC



REAR ROD END (LCA) - MAX EXTENSION

